

# TORQUE-LOCK & BRUSHES

## TORQUE-LOCK



### BRUSHES

12" Diamter SWEEPSALL Brush	CALL	AWPFT12
16" Diamter SWEEPSALL Brush	CALL	AWPFT16



### RODS

4" Fiberglass Torque Lock Connector Extension Rod .440" Diameter	CALL	AW59FT4
5" Fiberglass Torque Lock Connector Extension Rod .440" Diameter	CALL	AW59FT5
6' Heavy Duty Fiberglass Torque Lock Connector Extension Rod .480" Diameter	CALL	AW60XT6
7/8" x 3' ProFlex Torque Lock Connector Extension Rod	CALL	AWPFT783
7/8" x 5' ProFlex Torque Lock Connector Extension Rod	CALL	AWPFT785



### ADAPTERS

3/8" Female/Torque Lock Connector Female, 6 pack	CALL	AW38FTF
3/8" Male/Torque Lock Connector Male Adapter	CALL	AW38MTM
ProFlex Adapter Female/Torque Lock Connector Male	CALL	AWPFFTM
ProFlex Adapter Male/Torque Lock Connector Female	CALL	AWPFMTF
Adapter ProKleen Male/Torque Lock Connector Female	CALL	AWPKMTF

## BRUSHES

### MASTER SWEEP (wire)

6" Round Master Sweep	CALL	551206
8" Round Master Sweep	CALL	551208
12"x12" Master Sweep	CALL	551222
8"x12" Master Sweep	CALL	551282
8"x8" Master Sweep	CALL	551288

### POLY ROUND

6" Poly Round	CALL	552206
8" Poly Round	CALL	552208

### FLAT WIRE

12"x12" Flat Wire	CALL	553222
7"x7" Flat Wire	CALL	553277
8"x12" Flat Wire	CALL	553282

### WOOD HUB

8" Wood Core, brass screw in	CALL	554208
12" Wood Core, brass screw in	CALL	554212
16" Wood Core, brass screw in	CALL	554216

### BUTTON LOK

8" Wood Core, Button Lok	CALL	554219
12" Wood Core, Button Lok	CALL	554219
16" Wood Core, Button Lok	CALL	554217
Smoke Chamber Buttonlock Stiff "Don King"	CALL	55-6735B
Stinger Whip w/Buttonlok Adapter & Hub	CALL	55-7235
Stinger Whip Line for 7235	CALL	55-7235-9



### ADAPTERS

Adapter FPF/FPT P1770	CALL	55-1770
Adapter MU/FBL 2210	CALL	55-2210
Adapter FU/MBL 2211	CALL	55-2211
Adapter FPT/FBL 2238	CALL	55-2238
Adapter MPT/FBL 2239	CALL	55-2239
Drill Adapter Large	CALL	55-2258
Adapter FPT/MBL 2240	CALL	55-2240
Adapter FPT/FBL 2402	CALL	55-2402
Adapter MRK/FBL 2405	CALL	55-2405

**Order By 3:00 pm & Out the Same Day! 301-740-3488**